

# Scoreboard Directions

1. Turn on scoreboard (right side of counsel)
2. First, the screen will ask you if you want to start where you left off, push NO.
3. Next, the screen will then ask you to enter the model code, enter 008-3261.
4. Next, the screen will ask to use shot clocks, push NO
5. Next, the screen will ask to use penalty time out, push YES
6. To set the game time push the following:
  - i. SET
  - ii. TIME
  - iii. Enter your game time (17:00)
  - iv. Push YES
  - v. It will ask which period and enter 1, 2 or 3
7. To set scores push the following:
  - i. SET
  - ii. HOME SCORE
  - iii. Then the number
  - iv. Same goes for the Guest score
8. To set penalty minutes push the following:
  - i. SET
  - ii. HOME PNLTY
  - iii. Enter your penalty time (2:00)
  - iv. It will ask for the players number, enter that
  - v. Push YES
9. To clear penalty's push the following:
  - i. HOME PNLTY or GUEST PNLTY
  - ii. Then press PNLTY CLEAR
  - iii. It will ask if you want to clear it
  - iv. Push YES

