

SCOREKEEPER - Keep track of the score sheets. It is important that the scorekeeper records the periods of when and who scored (player #), who assisted (player #) the penalties, the start and stop of each penalty, and score. Also record the shots and saves on goal.

ABBREVIATIONS FOR SCORE SHEET			
HEAD CONTACT	HDC	INTERFERENCE	INTR
UNSPORTSMANLIKE CONDUCT	USLC	CHECKING FROM BEHIND	CFBH
SLASH	SLA	CROSS CHECKING	CROC
HIGH STICK	HIGH	KICKING	KICK
HOOK	HK	ELBOWING	ELB
HOLDING	HLD	KNEE	KNE
BENCH	BCH	FIGHTING	FI
TRIPPING	TRP	ROUGHING	RGH
BOARDING	BRD	MISCONDUCT	MIS
CHARGING	CHRG	SLASHING	SLSH
		TOO MANY MEN	TMM

DO NOT REMOVE FROM CADILLAC RINK

Clock Cheat Sheet – Cadillac RINK

To Set clock to Time of Day

1. Press Green Shift Button and Set Timer (T.O.D) button
2. Press #4/Yes button
3. Hit Enter for 12 hours
4. Press Clock Set and enter time (ex: 8:30 hit 0-8-3-0) press Enter

To Exit Time of Day

1. Press Green Shift Button and Set Timer (T.O.D) button
2. Press #6/No

To Start a New Game

1. Press Green Shift Button and the Period/NewGame Button
2. Press #4/Yes button

To Set Clock in Hockey Mode

1. Press Clock Set button
2. Enter Time (ex: 15 minute period hit 1-5-0-0) press Enter

To Set Period

1. Press Period button
2. Select 1, 2 or 3, Press Enter

To Add/Subtract Goals

1. Press Home Score (Blue) or Visitor Score (yellow)
2. Press number of goals, press Enter

To Set a 2 Minute (5 or 10 minute) Penalty

1. Press Home Penalty (blue) or Visitor Penalty (yellow)
2. Press +1/2:00 button
3. Enter Player Number, press Enter

To Set a 1:30 Minute Penalty (have to set the 2 minute penalty and then change it)

1. Press Home Penalty (blue) or Visitor Penalty (yellow)
2. Press Clear
3. Enter Player Number, press Enter
4. Enter new time, Put in 1:30 (0-1-3-0), press Enter

To Clear Penalty

1. Press Home Penalty (blue) or Visitor Penalty (yellow)
2. Enter Play Number, press Enter
3. Press Enter again to clear

To Set Clock for Break (penalty timer will NOT run)

1. Press Clock Set button TWICE
2. Enter Time (ex: 4 minute break hit 0-4-0-0), press Enter

To Set an Interval Timer (i.e. for Termites/Mites games)

1. Press Green Shift Button and Set Interval button
2. Press #4/Yess button
3. Press Set Interval button
4. Enter Time (ex: 2 minute shift hit 0-2-0-0), press enter
5. Horn will then sound every interval without having to press horn button